



AFTER CARE INSTRUCTIONS FOR WOCA OIL FINISHED END GRAIN FLOORING

DO NOT CLEAN BY WET MOPPING

Recommended Cleaning Products: Woca Soap Spray, Woca Refresh Spray, and Woca Commercial Oil Cleaner

The following maintenance program is offered using as little water as possible. Wood and water don't mix!

Caution: DIRECT WETTING WILL DAMAGE THE OIL FINISH AND THE WOOD FLOORING

The best way to care for your oil finished flooring employs daily sweeping or light vacuuming. Clean spills as they occur with a clean dry cloth, or use Woca Natural Soap Spray to spot treat spills. Use of other manufacture's products can be problematic.

The beauty of an oil finished floor is that it can be revitalized or refinished without the necessity for re-sanding. If your flooring has NOT been regularly cared for with Woca Soap Spray or Woca Refresh Spray, it will definitely benefit from a machine buff cleaning with the Woca Commercial Cleaning Oil. The Woca cleaning oil will keep the floor properly saturated with oil, helping to keep dirt at the surface rather than allowing it to settle in the wood. With proper ventilation and application, work can be done in the evening and walked on the following morning.

FOR DAILY AND WEEKLY CARE

We suggest minimal vacuuming (which can potentially pull fillers from the joints). Daily sweeping is recommended to remove sand or other abrasive particles that will harm the finish. Use a micro-fiber mist mop, or spray Woca Natural Soap Spray directly from the bottle to remove the dust and dirt. Wipe dry immediately.

FOR MONTHLY OR QUARTERLY CARE

Use Woca Refresh Spray in high traffic areas, by mist mop application, or from the spray bottle itself. Wipe dry immediately.

CAUTION: Woca Soap Spray and Woca Refresh Spray contain water, and therefore MUST be used by spray application only. Both products are available in White or Natural.

FOR QUARTERLY OR ANNUALLY OR ANYTIME CARE

In place of soap spray and refresh spray, use Woca Commercial Cleaning Oil. The cleaning oil contains no water, and therefore cannot harm the wood. The cleaning oil requires use of a slow speed buffer, buffing pads, and cotton cloths or towels.

Two methods of application:

1. Spray the commercial cleaning oil on a small area, then buff with soft absorbent cloths. Do not let sprayed areas rest for more than one hour. Be sure to buff off all excess oil. You can not over buff, so, if you are not sure you've buffed enough, buff again...Or
2. Soak a soft cloth in the Commercial Oil Cleaner, then wring it out reasonably tight. Place the cloth below a 3M white pad, and place the 3M pad and cloth below a standard 1100 RPM buffer. Buff clean with the cloth, then dry buff with a new dry cloth. Repeat the process if needed. Ask for our video showing this process. Again, if you are not sure you've buffed enough, buff again. Any excess oil left on the surface will attract dust and dirt, and can also show footprints. Approximate drying time: 8-12 hours.

High traffic commercial spaces may benefit from more frequent buff cleaning. For standard residential care or very light commercial office space, schedule a buff cleaning (typically) every 6 to 12 months.

WARNING: Rags, pads, or other waste products soaked with Woca Commercial Cleaning Oil may self ignite if improperly discarded. Remember, there is no water in this product, so immediately after use place all rags and waste in a sealed water-filled bag for proper disposal.

**CALL KASWELL FLOORING with any questions, and to order your Woca Products.
ph: 508-881-1520 www.kaswell.com**